



2x10 blocking

closed cell spray foam

closed cell spray foam

Block off rafter and spray closed cell spray foam on underside of roof decking and make this part of the roof unvented and isolated from the vented portion

These rafters get 1" of vent space between roof deck and spray foam and carry the intake air from birdblocking into the attic

Birdblocking